

Painting Tips for the Perfect Paint Job

Use these tips to make your painting more efficient and look great!

- ☐ To avoid lap marks, roll the full height of the wall and keep a wet edge. Lap marks are those ugly stripes caused by uneven layers of paint buildup. They occur when you roll over paint that's already partly dry. (In warm, dry conditions, latex paint can begin to stiffen in less than a minute!) The key to avoiding lap marks when doing DIY wall painting is to maintain a "wet edge," so each stroke of your roller overlaps the previous stroke before the paint can begin to dry.
- ☐ Mix several cans of paint in a large bucket for a consistent color throughout the room. Paint color may vary slightly from one can to the next. If you have to open a new can in the middle of a wall, the difference may be noticeable. Mixing the paints together eliminates the problem. It's best to estimate the amount of paint you'll need and mix it in a 5-gallon bucket (a process called "boxing").
- ☐ Let the paint dry, then cut the painter's tape loose for a perfect edge. Once paint is dry, you can't just pull the tape off the trim. Paint forms a film between the wall and the tape, and removing the tape tears pieces of dried paint off the wall. So before pulling off the tape, cut it loose. Wait for the paint to completely dry, at least 24 hours, then use a sharp utility knife or box cutter knife to slice through the film. Start in an inconspicuous area to make sure the paint is hard enough to slice cleanly.
- ☐ Paint the trim first, then the ceiling and walls. Pros usually follow a certain order when painting a room. They paint the trim first, then the ceiling, then the walls. That's because it's easier (and faster) to tape off the trim than to tape off the walls. And you certainly don't want to tape them both off! When painting the trim, you don't have to be neat. Just concentrate on getting a smooth finish on the wood. Don't worry if the trim paint gets onto the walls. You'll cover it later when painting the walls. Once the trim is completely painted and dry (at least 24 hours), tape it off (using an "easy release" painter's tape), then paint the ceiling, then the walls.
- ☐ Prime and texture wall patches to avoid a blotchy finish. Freshly painted walls often look blotchy. The color is uniform, but the sheen isn't consistent. This usually occurs over the holes and cracks you patched with a filler or drywall compound. The porous fillers absorb the paint, dulling the surface (a problem called "flashing"). When light hits these dull spots, they stick out like a sore thumb. The smooth patch also stands out in contrast to the slightly bumpy texture of the rest of the wall. A quick coat of primer is all it takes to eliminate flashing and texture differences. Primer seals the patch so paint won't sink in and look dull. To match texture, prime with a roller, feathering out the edges. Choose a nap thickness to match the surrounding wall texture (a 3/8-in. nap roller for smooth walls; 1/2-in. for textured).
- ☐ Clean dirty surfaces so the paint can form a strong bond. If you paint over dirty, oily surfaces, the paint will easily chip or peel off. So before painting, clean grimy areas with a deglosser or heavy-duty cleaner intended for prepaint cleaning. They work well to clean painted, varnished or enameled surfaces to improve the adhesion of the new paint. They're ideal for cleaning greasy or oily areas like kitchen and bathroom walls and removing hand marks around light switches and doorknobs.
- ☐ Roll paint along the edges for consistent texture. Corners and areas next to trim that are painted only with a brush have a noticeably different texture than the surrounding paint. To ensure the finished texture will be consistent in these areas, brush on the paint, then immediately roll it out before the paint dries. Use a 3-in. roller with a nap that's the same thickness as the roller used for the rest of the wall. Roll as close as you can without bumping the opposite wall or slopping paint onto the trim. Finish brushing on the paint and rolling it out in one area before moving on to the next section.
- ☐ Use cotton drop cloths rather than plastic. Spills and splatters happen, regardless of how careful you are. It's a lot easier to pre-prepare for them than to wipe them out of your carpeting or off your wood floor later. All it takes is canvas drop cloths in your work area (a 4-ft. x 15-ft. cloth costs \$15). The thick canvas stays in place, so you don't need to tape it, and you can use it to cover any surface. Plastic drop cloths are slippery to walk on or set a ladder on and don't stay in place. Even worse, paint spills on plastic stay wet, and they can end up on your shoes and get tracked through the house. Canvas is slippery on hard floors, so rosin paper (\$10 for 400 sq. ft. at home centers) is better over vinyl, tile and hard-wood. Tape the sheets together and to the floor to provide a nonslip surface.

☐ Feather out paint where you can't keep a wet edge. You can't cover large areas like ceilings, extra-tall walls or stairwells in single, continuous strokes, so the best way to minimize lap marks on these areas is to feather out the paint along the edges that you can't keep wet. The thinner, feathered coat of paint will avoid the buildup that causes the lap mark. To paint a large section without leaving lap marks, roll the nearly dry roller in different directions along the dry edge, feathering out the paint as you go. After completing the entire length of the wall or ceiling, move to the next section and paint over the feathered edges. For the second coat, apply the paint in the opposite direction. This crisscrossing paint application sharply reduces (if not eliminates) lap marks.

☐ Sand trim between coats for an ultra-smooth finish. One coat of paint usually won't hide the underlying color and sheen on trim. And if you don't sand the surface smooth between coats, the finish may have a grainy texture. For a smooth finish, sand the trim before applying each coat of paint. Sand the trim with a fine-grit sanding sponge. Sponges get into crevices where sandpaper can't go and let you apply even pressure. Then apply the first coat of paint, let it dry at least 24 hours, lightly sand it again for a completely smooth surface, and apply the second coat. After each sanding, vacuum the trim, then wipe it down with a tack cloth to remove the dust.

Make and Share Free Checklists

checkli.com