Boeing 737-800 - 08/17/17

For Microsoft Flight Simulator X

Pre-Start Checklist

◯ Parking Brake (SET)

◯ Throttle (IDLE)

◯ Fuel Flow (CUTOFF)

◯ BATT master Switch (ON)

◯ Panel Lights (ON if required)

◯ Hydraulic Pump Switches (ON)

◯ Landing gear level (CHECK DOWN)

◯ Flaps (UP)

◯ APU (START/CHECK RUN)

◯ APU Gen (ON/Check VOLTS)

◯ Fuel Quantity (Check)

◯ Pitot Headt/ De-Ice (OFF)

◯ Aircraft Lighting (OFF)

◯ Flight controls (FREE AND CORRECT)

◯ Passenger Signs (OFF)

◯ Check Weather (Atis,Flight Services)

◯ De-Ice (TEST/CHECK)

◯ Transponder (STANDBY)

◯ Beacon/Anti Collision Lights (ON)

Startup Checklist

◯ Thrust Levers (IDLE)

◯ Engine Area (CLEAR)

◯ Engine Start Switches (GND/IGN BOTH)

◯ Fuel Pump Switches (ON)

◯ Lft Engine Master starter switch (ON)

◯ Lft Engine at N2 > 20% Fuel Flow (CHECK ON)

◯ Lft Engine N1 increasing as N2 incr. (CHECK)

- ◯ Lft Engine Oil Pressure (CHECK)
- ◯ Lft Engine Generator Switch (ON)
- ◯ Repeat for Rgt Engine
- ◯ Fuel Pump Switches (OFF)
- ◯ APU Gen,APU (OFF)

Before Taxi Checklist

- ◯ Nav Lights (ON)
- ◯ Taxi Lights (ON)
- ◯ Heading/Altimeters (SET)
- ◯ Standby instruments (SET)
- ◯ Radio and avionics (SET FOR DEPARTURE)
- ◯ Autopilot (ON)
- ◯ Autothrottle (ON)
- ◯ F/D (ON)
- ◯ Autobrake (RTO)
- ◯ Elevator Trim (SET FOR TAKEOFF)
- ◯ Request taxi Clearance

Taxi Checklist

- ◯ Parking Brake (Release)
- ◯ Taxi to assigned runway (SPEED MAX 20Knots)
- ◯ Brakes/Gyro/Turn coordinator (CHECK DURING TAXI)

Before take-off Checklist

- ◯ Parking Brake (SET)
- ◯ Throttle (IDLE)
- ◯ Elevator Trim (SET for takeoff)
- ◯ Flaps (5 deg)
- ◯ Spoilers (RETRACTED)
- ◯ Flight Instruments (CHECK)
- ◯ Engine Instruments (CHECK)

- ◯ Takeoff DATA V1,VR,V2 (CHECK)
- ◯ Nav Equipment (CHECK)
- ◯ Landing Lights (ON)
- ◯ Taxi Lights (OFF)
- ◯ Strobe Light (ON)
- ◯ Pitot Heat (ON)
- ◯ De-Ice (AS REQUIRED)
- ◯ Transponder (ON)
- ◯ Request Takeoff clearance